

Written By: Iyonna L. Tynes



INTRODUCTION

Use this guide to replace a laptop battery which quickly runs out power.

Step 1 — Battery



- Ensure that the laptop is completely powered off, then flip it over to identify the battery latch located towards the bottom of the back panel.
- Push the latch to the unlocked position.

Step 2



- Gently take out the battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-15 04:46:38 PM.